

# HOW TO USE THE FIREPLACE

## *in Villa Iivari*

### 1 Switch off the air dryer system

Villa Iivari has an air dryer system in the entrance hall, switch it off.

### 2 Open chimney hatch


Chimney hatch is at the bottom of the chimney, open 30 cm outwards.

### 3 Open ash hatch

Ash hatch is a black little door under the fireplace window. Open about 5 cm. Once the fire is burning nicely, close the ash hatch (3) and adjust air from the lid (left-right), or keep the hatch on a small gap.

### 4 Adjust the airflow handle

To start the fire turn the airflow handle to **open** position. Once the fire is burning nicely, turn the switch to the **other** position and the fireplace starts storing heat.

Burn maximally the amount of one basket of logs at one time and let the fireplace cool down. 

Open



Other



### 5 Small chimney hatch

The fireplace only works correctly, if the small hatch is closed. Please don't touch.

### 6 Afterwards

When there are no glowing embers in the fireplace or ash hatch, then is the right time to close the chimney hatch (2).

**Close the chimney hatch at the right time - CO2 poisoning danger.**



#### Pro tip

Bring tomorrow's logs in today, they'll burn better.



**Suomenkieliset ohjeet kääntöpuolella.**

